

Rubber

type 1 (T20) Rubber 7 mm or less (free shapes)

Intended use with **HO**

Overcut: - [4 bars] +

type 2 (T21) Rubber 7 mm or more (free shapes)

Intended use with **HO**

Overcut: - [4 bars] +

type 3 (T22) Rubber straight lines

Similar to type 1, but more robust and with a larger overcut.

Intended use with **HO**

Overcut: - [4 bars] +

type 4 (T62) Rubber straight lines **TOP BLADE**

Intended use with **HO**

Overcut: - [4 bars] +

Folding Carton / Varnish Blankets

type F1 (M784) Folding carton

Intended use with **F1**

Overcut: - [4 bars] +

type F2 (T16) Folding carton

Intended use with **T1** **LO**

Overcut: - [4 bars] +

type F3 (T10) Folding carton / Varnish Blankets

Intended use with **T2**

Overcut: - [4 bars] +

type F4 (T11) Folding carton / Varnish Blankets

Intended use with **T2**

Overcut: - [4 bars] +

Corrugated Carton

type C1 (T17) Corrugated carton

Intended use with **LO**

Overcut: - [4 bars] +

type 3 (T22) Corrugated carton

Intended use with **HO** **LO**

*requires separate blade holder (LO)

Overcut: - [4 bars] +

Stickers

type S1 (T3) Sticker material / Kiss-Cut

Intended use with **KC**

Overcut: - [4 bars] +

Note: Overcut (X) depends entirely on material thickness (T)
 Double edged blades have a pre-cut and post-cut (overcut)

